



# Damage Mechanisms in High-Temperature Superconducting (HTS) Tapes

Delphine Domange, Marco Bonura, David Gancarcik, Cedric Hernalsteens, Carmine Senatore, Daniel Wollmann

With contributions from Andreas Oslandsbotn, Andreas Will, William Martin Sorensen, Jannik Lassen, Anne Kirstine Herskind



***Accelerator Physics – USPAS Winter 2024 – 02.02.2024***

# Outline

1. Superconducting material
2. Motivations: one failure case example
3. The HiRadMat-37 experiment
4. Critical current measurement
5. Conclusion



# Superconducting material

## Superconductivity

- Operation below the critical surface → No resistance
- Typically implies cryogenic temperature operation
- Used in accelerator magnets to provide high magnetic fields
  - NbTi used on LHC magnets
  - Nb<sub>3</sub>Sn used for the new HL-LHC triplet quadrupoles
- Newly developed materials provide
  - High-Temperature Superconductors (HTS) (if  $T_c \geq 77\text{K}$ )
  - Room temperature superconductors [1]

## HTS REBCO Tape


- Operation at 77K or at 4K with higher external magnetic field
- 0.2mm thick multilayer tape
- Considered for future colliders



# Motivations: one failure case

## Accelerator failure scenarios

- Beam losses: quenches → **Availability issue**
- Failure scenarios: possible long-term degradation of magnet coils? → **Machine protection issue**




Courtesy V. Raginel




**A large experimental campaign was started to assess the damage mechanisms and to quantify the damage limits of the different superconductors: LTS and HTS**

# The HiRadMat-37 experiment

Experimental table setup in the  
HiRadMat tunnel



The CERN accelerator complex  
Complexe des accélérateurs du CERN






# The HiRadMat-37 experiment


Cryostat



Second layer removed




Sample holders placed on the cryostat




# The HiRadMat-37 experiment

HTS samples holder  
6 batches of 7 samples



HTS samples holder after  
beam impact




HTS tape


Dimensions:

- Length: 60mm
- Width: 4mm
- Thickness: 0.2mm


Horizontal tape: Batch 1 - 4



Vertical tape: Batch 5 - 6





# HiRadMat-37: Post-beam-impact analysis







# HiRadMat-37: Monte Carlo simulation



# HiRadMat-37: Monte Carlo simulation

## From specific energy to temperature


$$Q = \int_T C_p(T) dT \quad \text{with } C_p \text{ specific heat capacity } [J \cdot kg^{-1} \cdot K^{-1}]$$



# HiRadMat-37: Monte Carlo simulation


## Hotspot values for Batch 1 and Batch 2

Sample	Hotspot Temperature [K]	Relative error	
		-	+
B1S1	352	1.99%	1.99%
B1S2	522	1.34%	1.34%
B1S3	694	1.01%	1.01%
B1S4	888	0.68%	0.56%
B1S5	1006	0.89%	0.80%
B1S6	1131	0.62%	0.62%
B1S7	1218	0.49%	0.49%
B2S1	328	5.79%	5.79%
B2S2	486	1.65%	1.44%
B2S3	646	2.48%	2.48%
B2S4	815	0.98%	0.86%
B2S5	954	1.05%	0.94%
B2S6	1046	0.86%	0.76%
B2S7	1148	0.96%	0.87%



# Critical current measurement

## Setup of the University of Geneva Lab



Removable tube on which the sample is fixed

Electro-magnet for the external magnetic field



Current supply

Cryostat with liquid helium: Measure at 4K or 77K

# Critical current measurement



Removable tube on which the sample is fixed via the sample holder



Voltage tap for the measurement

$AB \approx 20 \text{ mm}$

$CD \approx 15 \text{ mm}$



